



20-2042-52 - Windshield Frame to Body Seal

FITS: Many models of 1935-1936 Ford Passenger Cars & Wagons

Installing Windshield Seal to the Windshield Frame

STEP 1 - Remove windshield frame from car and be sure to clean all old rubber out of the groove.

STEP 2 - Find the bonded ends of the windshield rubber seal and start the rubber into the groove of the windshield frame at the bottom center.

Push rubber into groove at the same time slightly stretching the rubber as it goes into the groove section of the frame. Work rubber in as you go around the perimeter of the frame.

